



IMPORTANT TECHNICAL INFORMATION



PLEASE REVIEW CAREFULLY

Important Notice: New SPPG Probe Attachment Method

With the 3.5 software release, the SPPG probe/sensor (**Pic 1**) now attaches to the great toe using 1-inch self-adhesive Coban tape (**Pic 2**). This black, stretchy tape replaces the previous Velcro strip and securely holds the sensor while blocking ambient light.

How to Use Coban Tape:

1. Cut a 6-inch strip of Coban tape.
2. Wrap the tape around the sensor and toe with moderate tension (**Pic 3**).

A roll of Coban tape is included with each Cuff-Link system. Double-sided tape is also included as a secondary attachment option.

If you have any questions about the new SPPG probe, its functionality, or the attachment process, please don't hesitate to contact customer support. We're happy to help!



Pic 1



Pic 2



Pic 3

Customer Support: 800-267-5549