



ABI-Q

1. Remove all materials from packaging.
2. Check that inventory matches packing list.
3. Plug PVR unit into computer using included USB cable.
4. Use tubing assembly, as shown below, to attach inflation bulb, PVR box hardware, and cuff tubing.

NOTE: Care should be taken when attaching hoses. Do not overtighten connectors or damage may occur.

